


TO FILL YOUR PARKER 45 CONVERTIBLE PEN

From an ink bottle:

1. Pull cap off pen, unscrew barrel from front end of pen.
2. Immerse point in ink, press ribbed bar on converter four times.
3. Remove excess ink from point with absorbent tissue and replace barrel.



With a cartridge:

1. Pull cap off pen, unscrew barrel from front end of pen.
2. Pull out converter.
3. Insert cartridge into front end of pen, push in gently until you feel the cartridge seat itself.
4. Replace barrel.



P *Guarantee*

ARKER will repair or replace your pen free if it fails to perform due to defects in materials or workmanship. Should this occur, just return it to us.

THE PARKER PEN COMPANY • JANESVILLE, WISCONSIN 53545